6/11/2021 TestOut LabSim

## 3.3.4 Motherboard Installation Facts

Repairing a motherboard is beyond the skill of most technicians and it is almost always cheaper and faster to purchase a new one. You might also need to replace your motherboard to add new features or to upgrade the processor. Use the following process when installing or replacing a motherboard:

- 1. If you are replacing an existing motherboard, document the current CMOS settings. You might need these settings to configure the new motherboard.
- 2. Install the CPU, heat sink, and memory before installing the motherboard in the case.
- 3. Insert the I/O shield into the case.
- 4. Fasten standoffs to the case, being sure to match the hole pattern on the motherboard. The standoffs prevent the motherboard circuits from touching the system case.
- 5. Install the motherboard, securing it to the standoffs with insulated washers and screws.
- 6. Connect the power and accessory cables:
  - Connect the ATX power cable and the CPU power cable.
  - Connect the CPU fan power cable.
  - Connect case wires (e.g., power switch, reset switch, and drive activity and power lights).
  - Connect any case fan cables.
- 7. Connect drives to SATA connectors.
- 8. Install additional devices in expansion slots.
- 9. Connect wires for front/top panel ports (e.g., USB, audio, or eSATA).
- 10. Document the settings of the new motherboard.

Consult the motherboard's documentation to identify the location and configuration of front/top panel ports and case wires.

Copyright © 2021 TestOut Corporation All rights reserved.